How to turn the system ON and OFF.

Press Start button on the 10" touch panel located on the top of the podium desk

*This will turn on the projector and lower the projector screen.

Chooseone of the input sources.

To turn the projector ON,OFF, or Mute press the corresponding button on the touch panel *** Pressing ON will turn on the projector and lower the projector screen.